



1-3/8"




1-3/8" 3/8" Flat Panel - NS



1-3/8" 9/16" Raised Panel - NS




1-3/8" 7/8" Raised Panel - NS



1-3/8" 3/8" Flat Panel Bolection large - NS



1-3/8" 3/8" Flat Panel Bolection small - NS



1-3/8" 7/8" Panel Bolection large - NS




1-3/8" 7/8" Panel Bolection small - NS

RP	Raised Panel
FP	Flat Panel
NS	No Sticking
RS	Round Sticking
SS	Square Sticking


1-3/4"




1-3/4" 3/8" Flat Panel - NS



1-3/4" 7/8" Raised Panel - NS




1-3/4" 1-1/4" Raised Panel - NS - 20 min.



1-3/4" 1-1/4" Raised Panel - NS




1-3/4" 5/8" Flat Panel - NS - 20 min.




1-3/4" 3/8" Flat Panel Bolection large - NS



1-3/4" 5/8" Flat Panel Bolection small - NS - 20min.



1-3/4" 7/8" Panel Bolection large - NS



1-3/4" 1-1/4" Panel Bolection small - NS