


1-3/8"




1-3/8" 3/8" Flat Panel - 1/4" SS




1-3/8" 9/16" Raised Panel - 1/4" SS




1-3/8" 7/8" Raised Panel - 1/4" SS




1-3/8" 3/8" Flat Panel Bolection large - SS



1-3/8" 3/8" Flat Panel Bolection small - SS



1-3/8" 7/8" Panel Bolection large - SS




1-3/8" 7/8" Panel Bolection small - SS

RP	Raised Panel
FP	Flat Panel
NS	No Sticking
RS	Round Sticking
SS	Square Sticking

1-3/4"



1-3/4" 3/8" Flat Panel - 1/4" SS



1-3/4" 7/8" Raised Panel - SS




1-3/4" 1-1/4" Raised Panel - SS




1-3/4" 1-1/4" Raised Panel - SS - 20 min.




1-3/4" 5/8" Flat Panel - SS - 20 min.




1-3/4" 3/8" Flat Panel Bolection large - SS



1-3/4" 5/8" Flat Panel Bolection small - SS - 20min.



1-3/4" 7/8" Panel Bolection large - SS



1-3/4" 1-1/4" Panel Bolection small - SS